



Memory card for easy500/700, 32kB

Part no. EASY-M-32K
Catalog No. 270884

EL-Nummer 4519727
(Norway)

Delivery program

For use with			easy500 easy700
Memory size		KByte	32-kB module
Information relevant for export to North America			
Product Standards IEC/EN see Technical Data; UL 508; CSA C22.2 No. 142-M1987; CSA C22.2 No. 213-M1987; CE marking			
UL File No. E135462			
UL Category Control No. NRAQ			
CSA File No. 012528			
CSA Class No. 2252-01 + 2258-02			
North America Certification UL listed, CSA certified			
Degree of Protection IEC: IP20, UL/CSA Type: -			

Design verification as per IEC/EN 61439

Technical data for design verification			
Operating ambient temperature min.		°C	-25
Operating ambient temperature max.		°C	55

Technical data ETIM 6.0

PLC's (EG000024) / PLC memory card (EC000192)			
Electric engineering, automation, process control engineering / Control / Programmable logic control (SPS) / SPS memory unit (ecI@ss8.1-27-24-22-12 [AKE535011])			
Type of memory			-
Memory size		kByte	32

Approvals

Product Standards			IEC/EN see Technical Data; UL 508; CSA C22.2 No. 142-M1987; CSA C22.2 No. 213-M1987; CE marking
UL File No.			E135462
UL Category Control No.			NRAQ
CSA File No.			012528
CSA Class No.			2252-01 + 2258-02
North America Certification			UL listed, CSA certified
Degree of Protection			IEC: IP20, UL/CSA Type: -

Additional product information (links)

Instruction leaflet "easy control relays" IL05013015Z (AWA2528-2105)	
Instruction leaflet "easy control relays" IL05013015Z (AWA2528-2105)	ftp://ftp.moeller.net/DOCUMENTATION/AWA_INSTRUCTIONS/IL05013015Z.pdf
Instruction leaflet "easy control relays" IL05013015Z (AWA2528-2105)	ftp://ftp.moeller.net/DOCUMENTATION/AWA_INSTRUCTIONS/IL05013015Z2016_04.pdf
Manual "easy500, easy700 control relays" MN05013003Z (AWB2528-1508)	
Handbuch Steuerrelais easy500, easy700 MN05013003Z (AWB2528-1508) - Deutsch	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN05013003Z_DE.pdf
Manual "easy500, easy700 control relays" MN05013003Z (AWB2528-1508) - English	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN05013003Z_EN.pdf